



HLRM 140-4S

Load Diagram with fixed hook at Harbour Condition




DIAGRAM REFERRED TO CRANE AT "0" SEA ROUGHNESS OR AT HARBOUR CONDITION IF THE CRANE IS USED OFF SHORE IN ROUGHER SEA CONDITIONS, CONTACT THE SUPPLIER TO ESTABLISH LOADING CAPACITIES OR REDUCTION PARAMETERS.